



Party Rentals & Sales
Construction Equipment
Homeowner Tools
Public Storage
440.942.6106

WWW.SUNRENTAL.COM

Instructions

MARGARITA MACHINE

Preparation Instructions:

- Visit SUNRENTAL.COM and click “How to Video” tab for step-by-step video instructions.
- Power: As part of your rental, we provide an extension cord. Connect extension cord to black cord on front of machine. Use only the extension cord we have provided and plug directly into a wall outlet. If renting more than one machine, they must be on different circuits. If these instructions are not followed, it can impact the operation and performance of the machine.
- Place machine on tabletop.
- Before filling, make sure the barrel is locked down or unit will leak.
- Allow the unit 6 inches of free space on left and right sides of machine. Do not push against wall. Allow for proper air flow of side vents.

Operating Instructions:

- Pour 1 half gallon jug of Sun Rental mix into barrel. Mix can be refrigerated beforehand to help speed up slush time!
- Pour 2 gallons of cold water into barrel. Very cold water also helps with slush time!
- Start machine by flipping power button on (top button on side of machine).
 - “I” means on.
 - “O” means off.
- Turn temperature setting to Snowflake Icon (“I” - 2nd button, 2nd row of buttons on side of machine).
- Note: it can take approximately 45 minutes to 2 hours to slush (depending on temperature of environment and liquid).
- Do not add alcohol to machine until mixture is fully slushed. Alcohol does not freeze.
- If making more than one batch of the same flavor, you can refill barrel once slush is half gone. Then pour half of the Sun Rental mix into barrel and 1 gallon of cold water. Allow time to slush.
- Note: If slush mixture is too thick, turn temperature setting to Raindrop Icon (“I” – 2nd button, 2nd row of buttons on side of machine). Once thinned out, turn back to Snowflake Icon.

Cleaning Instructions:

- Drain all liquid from barrel.
- Fill barrel with clean warm water.
- Drain Water from barrel.
- Wipe down outside of unit with a damp cloth.
- Please do not disassemble. One of our Sun Rental Team Members will clean and sanitize.
- If slush machine is returned without being rinsed of all mixture, a minimum cleaning fee of \$50 will be charged to the card on file.

Helpful Hints:

- Always keep machine upright. Never lay on side (transportation).
- Keep in mind other items you have plugged into circuit you choose to plug the slush machine into. This can impact the performance of the slush machine.
- We recommend keeping the machine indoors. If using outdoors, mix can take longer to slush or will stay as a liquid. Heat works against the machine, making it harder to slush and keep cold.

UNDERSTAND YOUR RENTAL CONTRACT / KNOW YOUR RESPONSIBILITY FOR THE EQUIPMENT YOU HAVE RENTED

The guidelines are not intended to be all-inclusive, complete descriptions of safe practices, or to supplement or replace other additional precautionary measure to cover usual or unusual conditions or situations where common sense might otherwise dictate. Accordingly, Sun Rental Center Inc disclaims all liability for, and makes no warranty or guarantee, the accuracy or applicability of this information in any situation.

Copyright © 2010 Sun Rental Center Inc. - Party - Tools - Storage